



- NOTE:**
- ① MAINTAIN A MINIMUM OF 3' CLEARANCE FREE OF ALL PLANTINGS & STRUCTURES AROUND HYDRO-GUARD DEVICE.
 - ② BOLLARDS SHALL BE REQUIRED ON A CASE-BY-CASE BASIS HYDRO-GUARD DEVICE.
 - ③ AUTOMATIC FLUSHING DEVICE SHALL BE INSTALLED ON ALL "DEAD END" LINES, CONSTRUCTION LINES, PHASE LINES AND CUL-DE-SAC LOOPS.
 - ④ HYDROGUARD DEVICE SHALL BE SET BEHIND RIGHT OF WAY LINE AND ON PROPERTY LINE.
 - ⑤ SODDING MUST BE INSTALLED BEFORE HYDRO-GUARD IS ACTIVATED.

HYDRO-GUARD AUTOMATIC FLUSHING DEVICE